




Litepanels™ 4x4 Frame - Assembly Instructions



LP-4x4 Frame/Yoke/power supply

1. To attach the yoke, insert the bolts on either side of the frame and secure until the bolt head locks to the nut inside.
2. Mount the entire LP-4x4 frame/yoke assembly onto a tripod stand and secure with stand hardware.
3. Remove the yoke from sixteen (16) LP-1x1.
4. Open the hinged top of the LP-4x4 frame and slide four (4) LP-1x1 into each column of the frame.
5. Close the top and secure with latches situated at side/top of the frame.
6. Attach the dedicated LP-4x4 power supply to the horizontal cross member of the LP-4x4 frame for with supplied hardware.
7. Attach eight (8) connector/cable assemblies between the power supply and each of the LP-1x1.
8. Apply power and the LP-4x4 is ready for operation.